# GreenEye Monitor

**CT & PT Settings** 



#### Ver 1.0

2017-10-09 © Copyright Brultech Research Inc. 2017



### **CT SETTINGS**

The GEM has two CT parameters for each channel which need to be configured: CT "Type" and CT "Range. These are variables used to scale the CT output to properly represent the sensed current. When setting up the GEM, there is a drop-down menu to select the CT model being used on any particular channel. This selection will automatically select the CT type and range for the selected model.

### CT "Type"

The CT "type" is a number between 1 and 255 which scales the measured CT signal proportionally. It is advisable to use a variable between 127 and 255 for the "type". If the desired scaling cannot be obtained, this is where the "range" comes into play.

## CT "Range"

The CT "range" is typically between 2 and 4. This number is the number of time the CT measurement is divided by two. For example, if a connected CT with the CT range set to "3" is measuring a load displaying 400 watts, reducing the range from "3" to "2" will cause the wattage to double: 800 watts. Similarly, increasing the range from "3" to "4" will scale the signal by half: 200 watts.

## **Types of CT Output Signal**

Other than the fact that CTs come in various styles (donut, split-core, clamp-on) the signal it generates may be voltage signal (Type A) or current signal (Type B). Both CT types sense the load current! It's only the signal that represents the sensed current that differs. Because of this the GEM terminals that the CT will be connected to will differ. Each GEM CT input has a terminal block with four terminals. Terminal #1 is located towards the bottom of the GEM while #4 is towards the top. The CT chart below indicates which terminals to use based on the CT model.

CT Model	Style: D(donut)	All GEMs CT Type	All GEMs CT Range	CT Output	One CT Terminal	Two CTs Terminal	
	S (split-core)	/-		Type			
Micro-40	Donut	211	4	В	2 & 3	2 & 3 / 2 & 3	
Micro-50	Donut	210	4	В	2 & 3	2 & 3 / 2 & 3	
Micro-80	Donut	210	4	В	2 & 3	2 & 3 / 2 & 3	
Micro-80-I							
Micro-100	Donut	212	3	В	2 & 3	2 & 3 / 2 & 3	
SPLIT-30	Split-core	205	4	Α	1 & 2	1 & 2 / 3 & 4	Optional capacitor
							across terminal 1 &
							4
SPLIT-60	Split-core	180	4	Α	1 & 2	1 & 2 / 3 & 4	
SPLIT-100	Split-core	146	3	Α	1 & 2	1 & 2 / 3 & 4	
SPLIT-100-I							
SPLIT-200	Split-core	144	2	Α	1 & 2	1 & 2 / 3 & 4	
SPLIT-200-I							
SPLIT-	Split-core	231	2	Α	1 & 2	1 & 2 / 3 & 4	
400/600							
Other							
SPLIT-170	Split-core	137	2	В	2 & 3	2 & 3 / 2 & 3	No resistor.
							CAUTION High
							Voltage
SPLIT-170	Split-core	245	3	Α	1 & 2	1 & 2 / 3 & 4	With resistor
TT-100	Split-core						

© Bruitech Research Inc. 2 www.bruitech.com



# **PT SETTINGS**

The Potential Transformer (PT) is connected to the power line (120V or 240V, etc) and reduces the voltage to a low voltage proportional to that of the line voltage. It also provides galvanic isolation from the power line for safety purposes. The PT "type" and "range" works on the sample principle as that described for the CT "type" and "range".

# Tweaking the voltage measurement

If you have a True RMS DMM (and some electrical and safety knowledge) you can fine tune the GEM so that it displays the same as your DMM does. This is done by increasing or decreasing the PT "type" by increments of one at a time to get the closest voltage match.

PT Model	GEM with black PCB	GEM with blue PCB	Connection	Remarks
	(with PT gain jumper)	(no PT gain jumper)	Method	
	PT Type/Range	PT Type/Range		
Newest 12Vac 400mA	205/3	253/4	3.5mm mono	
PTs (2017) 60Hz			phone plug	
Previous "Brultech"	194/4	238/4	3.5mm mono	
labeled 12Vac 500mA			phone plug	
60Hz				
Early "CUI Stack"	186/3	-	3.5mm mono	
brand 12VAC 300mA			phone plug	
60Hz				
European style PT	160/2	196/3	3.5mm mono	
240V/12Vac 50Hz	GEM set to 50Hz	GEM set to 50Hz	phone plug	
Brultech PT-480	<b>60Hz:</b> 208/3 remove	<b>60Hz</b> : 209/3	3.5mm Stereo	
Brown & Blue leads	PT gain jumper!	<b>60Hz:</b> 210/2	phone plug.	
(Line voltage input)	<b>50Hz:</b> 210/3 remove		Low voltage	
Black and White leads	PT gain jumper!		from PT	
(Low voltage output)			connected to	
50Hz or 60Hz			"ring" and	
			"sleeve" of	
			stereo plug. Tip	
			not connected!	
			OR	
			Mini USB	
			Willin OJD	

© Brultech Research Inc. 3 www.brultech.com